









Warning :

- Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment.
- To prevent possible scratches and damage, this furniture must be assembled on a soft surface such as a blanket or carpet.




30725 / 30759
Uphost Chair 2in


Components and Hardware List

 <p>Chair Back 1 Pc.</p>	 <p>Back Leg 2 Pcs.</p>	 <p>Front Leg 2 Pcs.</p>		
 <p>Allen Head Bolt M8-32 x 50mm 8 Pcs.</p>	 <p>Lock Washer Ø9 x Ø13mm 8 Pcs.</p>	 <p>Flat Washer Ø8 x Ø20mm 8 Pcs.</p>	 <p>Allen Key 4 x 110mm 1 Pc.</p>	

STEP 1:



STEP 2:



Complete

